



SETSCO SERVICES PTE LTD

18 Teban Gardens Crescent
Singapore 608925
Tel : (65) 6566 7777
Fax: (65) 6566 7718
Website: www.setsco.com
Business Reg. No. 196900269D

Your Ref:

Our Ref: **FB58222/T**
TEST REPORT

Date: 20/04/2011

Page 1 of 2

(This Report is issued subject to the terms & conditions set out below)

Subject : Antimicrobial efficacy test on one sample of 'Safeguard Plus Compact Laminate (High Pressure Laminate)' was submitted by Greenlam Asia Pacific Pte Ltd on 31/03/2011 and testing commenced on 04/04/2011.

Test For : **Greenlam Asia Pacific Pte Ltd**
18 Sungei Kadut Street 2, Level 2
Singapore 729236
Attn: Ms Lin Huiping

Test Method : Japanese Industrial Standard – JIS Z 2801: 2000

Test Organisms: *Escherichia coli* ATCC 8739
Staphylococcus aureus ATCC 6538P
Methicillin Resistant *Staphylococcus aureus*
(MRSA) ATCC 43300
Pseudomonas aeruginosa ATCC 9027
Salmonella typhimurium ATCC 14028

Sample Ref :

Lab Sample ID No:	Sample Description:
FB58222001	Safeguard Plus Compact Laminate / High Pressure Laminate (60 coated pieces – 50mm x 50mm)


Terms & conditions:

- (1) The Report is prepared for the sole use of the Client and is prepared based upon the item submitted, the services required by the Client and the conditions under which the Services are performed by SETSCO. The Report is not intended to be representative of similar or equivalent Services on similar or equivalent items. The Report does not constitute an endorsement by SETSCO of the item.
- (2) SETSCO agrees to use reasonable diligence in the performance of the Services but no warranties are given and none may be implied directly or indirectly relating to the Services, the Report or the facilities of SETSCO.
- (3) The Report may not be used in any publicity material without the written consent of SETSCO.

Results of active bacteria on control and test sample after 24 hours of incubation at 35°C

Test Organisms	Blank Control		FB48647001 (Test sample)		Log reduction
	cfu/piece	Log value	cfu/piece	Log value	
<i>Escherichia coli</i>	1.6 x 10 ⁵	5.2	<10	<1	4.2
<i>Staphylococcus aureus</i>	3.5 x 10 ⁴	4.5	<10	<1	3.5
Methicillin Resistant <i>Staphylococcus aureus</i>	1.0 x 10 ⁴	4.0	<10	<1	3.0
<i>Pseudomonas aeruginosa</i>	1.8 x 10 ⁵	5.3	1.6 x 10 ³	3.2	2.1
<i>Salmonella typhimurium</i>	1.1 x 10 ⁵	5.0	<10	<1	4.0

Conclusion: Based on the results obtained, the sample as received has achieved the Antimicrobial efficacy of not less than 2 log reduction in accordance with JIS Z 2801:2000.


 KEITH LEE
 SENIOR MICROBIOLOGIST
 BIOLOGICAL & CHEMICAL TECHNOLOGY DIVISION